

LED Jogging Vest

Thank you for purchasing our LED Vest.

Included:

- LED Jogging Vest (Exhibit A)
- 2 CR2032 Batteries (Exhibit C)



A

Operation of the LED Vest:

1. Remove the batteries from the yellow sleeves and simply remove the paper tab to start the batteries. (Exhibit B)
2. Use the power/function button on the front of the vest (Exhibit C) to turn the functions on: Fast Flash, Slow Flash, On, and Off.
3. When the LEDs start to dim, turn the vest off, remove the battery, and simply replace them.
4. Press the On/Off button on the front of the vest to illuminate the LEDs on the front and On/Off button on the back to illuminate the back LEDs (Exhibit D)



B

*note that one battery is located in the front of the vest and a separate battery in the back of the vest.

CR2032



C

Care and Maintenance:

- Don't expose the vest to arc flashes or fire hazards.
- Don't submerge in water or expose the battery, switch, or wiring to direct or excessive moisture.
- Store in a dry place away from direct sunlight.
- Inspect for damage to magnetic connections and electrical components before each use.
- Remove batteries before cleaning
- Machine wash separately on a gentle cycle. Hang to dry and do not wash more than 20 times.
- DO NOT iron, bleach, dry clean, or put in the dryer.



D



Warranty:

All products and accessories are subject to a 1-year warranty from the date of purchase.



Additional Products & Accessories



Sign Covers



12"/18"/24" Paddles



Charger/Battery



LED Vests Class 2 & 3



LED Headlamp



Poles



LED Cone Ring Light



Solar LED Signs